

# FastRIP™ Technical Support Sheet

U.S. Screen Printing Institute  
1901 E 5th Street • Tempe, Arizona USA  
Tech Support (480)929-2937 • Fax (480)929-0766  
Email: support@usscreen.com

Support Form # **FR116**

Effective 6-1-05

## FastRIP Setup in Mac OS X 10.4.x ( Tiger )

FastRIP Mac OS X will work 10.4.x ( Tiger ). The printer cables that will work are USB to Parallel, USB to USB, or Ethernet cable. Firewire cables will NOT work with FastRIP Mac OS X. Below are instructions to add the FastRIP Print Driver. For installation of FastRIP follow the instructions from the FastRIP manual.

1. Install FastRIP Mac OS X. Refer to the FastRIP manual.
2. Turn the Epson printer ON. Connected the printer cable from the computer to the printer.
3. Go to Macintosh HD/Applications/Utilities. Double click on Printer Setup Utility.
4. Click and highlight the Epson printer. It might be named Stylus Pro \*, Stylus Photo \*, or Stylus Color \*.
5. Click in the Name box and change the name to something like FastRIP. If you have an Epson 7600 or 9600 printer you may want to add Full or Sheet at the end to know if you are printing by cut sheet or roll film.
6. Bring the Print Using menu down. Select FastRIP. Under Model select the PPD for your printer.
7. Click Add. In the Printer List the new FastRIP Print Driver will appear.
8. Plug the USB Dongle into a USB port on the computer.
9. Open FastRIP. A blue tab or button will have the name of the FastRIP Print Driver created.

